
RECESS-IT®

All Recess-It products are made of corrosionresistant, alloyed aluminum with a waterproof, anti-fracture coating and aggregate bonding base

Product

Description



- All products feature rolled flange for use with any trim style.
- Required wall fasteners are supplied with each product.
- Recess-It® products are made in the U.S.A.







Our Products

All of our products are designed for superior performance with minimal effort for the installer. Our products provide maximum flexibility to field-encountered issues, materials and/or designer-specified requirements. They are engineered to meet and exceed standards set forth by many industry related organizations. Expensive waterproofing systems have also been eliminated.

All of this while providing a cost-effective, off-the-shelf value to the installer.

Have questions, or need locator assistance for a retailer near you,

Please call us: (800)382-9653 M-F 9am-3pm Pacific time or 24 hr. msg.

www.innoviscorp.com



RECESS-IT®



Recessed-shelf Installation made easy

Visit us at our website:

www.innoviscorp.com

RECESS-IT®



STEP 1

Place Recess-It unit level at desired location with flange facing out. When positioning the unit, be careful not to interfere with any structural wall framing members. Trace perimeter of Recess-It on substrate and then place unit aside. Enlarge marked layout by 5/8" on all sides and cut out.

Also consider BETTER-BENCH®









STEP 2

Add a continuous bead of adhesive caulk along back of mounting flange, then secure to wall cavity using the supplied wall fasteners. (Galvanized roofing nails may be substituted.) Use a hand screwdriver or a power screwdriver on a low-resistance setting to tighten all fasteners. **DO NOT OVERTIGHTEN**



IMPORTANT:

Thickness of Recess-It mounting flange should be minimalized to provide a flush wall surface for the finish tile (or other finish material). In some cementitious substrates, you may be able to grind the perimeter of the cut-out for the width and depth of mounting flange prior to installation; otherwise, install unit, and then use bonding material (thin-set/mastic) to "feather" the edge of the unit for a distance of 8"-12" and allow to set firm prior to continuing with finish tile.



STEP 3

Finish as desired using bonding products suitable for finish surface material being applied.

Note: All Recess-It products have a predetermined slope for the bottom surface. This may be reduced or enhanced by using a thicker bed of bonding material at the front or rear of horizontal plane as necessary. **Do not adjust slope to angle backward toward rear of unit.**



OPTIONAL INSTALLATION

FLOATING-SHELF™

Place the Floating Shelf directly on top edge of selected tile course. Apply surface bull-nose tile (SBN) or other finish material to top and bottom of Floating Shelf by using thin-set or mastic to "sandwich" shelf unit. Allow front edge of applied tiles to extend 1/8" minimum to allow for grout coverage of shelf.